ERVICE INFORMATIO



Merlin Xtreme

Regular Maintenance

Belt Adjustment

- Check the condition of drive belts, ensuring they are aligned and properly tensioned to avoid any unnecessary belt wear.
- Remove both guards for access when tensioning belts; ensure belts are running in line after adjustment.

NOTE: The pulleys are fitted with taper locks which have 7 screws to tighten and 3 holes to aid removal in the pulley centers.









