

HY REACH SUPER E, PA35, PA93E, PA94, PA95

Wiring circuit

A common earth lead identified by a number 1 on its sleeve is wired in parallel to all the solenoids. The individual circuit leads are similarly identified with numbered sleeves.

For carrying out maintenance work on the machine when the protective cover is removed, disconnect the power supply at the jack plug on the electric control box. This will avoid any accidental short circuiting and possible fuse failure.

NOTE:- BROWN FEED INTO SWITCHBOX MUST BE BATTERY +

