

SCREEN CONTRAST ADJUSTMENT – v.3 Armrest Controls

Later versions of the v.3 Proportional Armrest Controls that are installed with v.3.07 software feature adjustable screen contrast. Adjustments to the contrast settings are made as follows:

- Power up the armrest
- Press and hold both left (<) and right arrows (>) simultaneously for three seconds until the option menu is displayed.
- Scroll right (>) until the LCD option is shown
- Press the 'Tick' button.

The screen will now display the option 'Contrast Up' and 'Contrast Down' Select the option you require and press the 'Tick' button in increments until the desired contrast is achieved.

CAUTION: If over adjusted the screen will become either too dark or too light and you will no longer be able to read the on-screen instructions – If this should occur take care not to press any of the buttons other than the arrow keys or tick button as you may inadvertently enter and change the settings within a different menu.

If this should happen, you can return to the contrast menu using the following instructions:

Power off and re-start the procedure – you will now need to count the second's and the number of menus that you need to scroll through to get back to the options as described below:

- Press and hold both arrow keys (<) (>) simultaneously for three seconds.
- Scroll either right (>) 9 times or left (<) 5 times
- Press the 'Tick' button.

You are now back to the LCD screen contrast menu – simply press the 'tick' button once and if no change then press the left arrow (<) once and then the 'tick' button and the screen contrast will now become either lighter or darker and the visibility of the display will return.

